



COMPRESSED HEIGHT
 (IN CAR AT ROAD HEIGHT)

FREE HEIGHT - FULL DROOP
 (SPRINGS STILL HELD
 IN PLACE, NO SLOP)